

ZANTIA®

Inspired by *Comfort!*

INSTRUCTION MANUAL

INSTALLATION, USER AND MAINTENANCE



ALL-IN-ONE HEAT PUMP - DOMESTIC HOT WATER

REGINA SMART

100L

Thank you for purchasing our product. Read this manual carefully before installing or operating your new pellet boiler. Make sure to save this manual for future reference.

TABLE OF CONTENT

| | |
|---|----|
| INTRODUCTION..... | 3 |
| This manual..... | 3 |
| The unit..... | 3 |
| SAFETY INSTRUCTIONS | 4 |
| Warning | 4 |
| Caution..... | 6 |
| ITEMS INSIDE PRODUCT BOX..... | 7 |
| OVERVIEW OF THE UNIT..... | 8 |
| Parts and descriptions | 8 |
| Dimensions | 9 |
| How to replace the magnesium anode..... | 10 |
| Schematic overview of the water and refrigeration circuit | 10 |
| INSTALLATION | 11 |
| Transportation | 11 |
| Required service space | 12 |
| Installation overview..... | 13 |
| Installation positions..... | 14 |
| Water loop connection | 15 |
| Water affusion and water emptying..... | 15 |
| Wire connection | 16 |
| Trial running..... | 16 |
| OPERATION THE UNIT..... | 17 |
| User interface and operation..... | 17 |
| LCD icons..... | 20 |
| PARAMETER CHECKING AND ADJUSTMENT..... | 21 |
| Parameter list..... | 21 |
| Malfunctioning of the unit and error codes | 22 |
| MAINTENANCE | 24 |
| TROUBLESHOOTING..... | 24 |
| ENVIRONMENTAL INFORMATION | 25 |
| DISPOSAL REQUIREMENTS | 25 |
| WIRING DIAGRAM | 26 |
| TECHNICAL SPECIFICATION | 27 |
| TEMPERATURE SENSOR R-T CONVERSION TABLE..... | 28 |



READ THIS MANUAL CAREFULLY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY.KEEP IT IN YOUR FILES FOR FUTURE REFERENCE.



BEFORE OPERATING THE UNIT, MAKE SURE THE INSTALLATION HAS BEEN CARRIED OUT CORRECTLY BY A PROFESSIONAL DEALER. IF YOU FEEL UNSURE ABOUT OPERATION, CONTACT YOUR DEALER FOR ADVICE AND INFORMATION.

INTRODUCTION

This manual

This manual includes the necessary information about the unit. Please read this manual carefully before you use and maintain the unit.

The unit

The hot water heat pump is one of the most economical systems to heat the water for family domestic use. Using free renewable energy from the air, the unit is highly efficient with low running costs. Its efficiency can be up to 3 ~ 4 times more than conventional gas boilers or electrical heaters.

Waste Heat recovery

Units can be installed near the kitchen, in the boiler-room or the garage, basically in every room which has a large number of waste-heat so that the unit has the higher energy efficiency even with very low outside temperatures during the winter.

Hot water and dehumidification

Units can be placed in the laundry room or clothing room. When it produces hot water it lowers the temperature and dehumidifies the room as well. The advantages can be experienced particularly in the humid season.

Storage room cooling

Units can be placed in the storage room as the low temperature keeps the food fresh.

Hot water and fresh air ventilation

Units can be placed in the garage, gym, basement etc. When it produces hot water, it cools the room and supplies fresh air.

Compatible with different energy sources

Units can be compatible with solar panels, external heat pumps, boilers or other different energy sources.

Ecological and Economical Heating

Units are the most efficient and economical alternative to both fossil fuel boilers and heating systems. By making use of the renewable source in the air, it consumes much less energy.

Compact design

Units are especially designed for offering sanitary hot water for family use. Its extremely compact structure and elegant design are suitable for indoor installation.

Multiple Functions

The special design of the air inlet and outlet makes the unit suitable for various ways of connections. With

different ways of installation, the unit can work as just a heat pump but also as a fresh air blower, a dehumidifier, or an energy recovery device.

Other features

Stainless steel tank and a magnesium stick assure the durability of components and the tank.

High efficiency compressor with R134a refrigerant.

Electrical element available in the unit as a back-up, assuring constant hot water even in extreme cold winters.

SAFETY INSTRUCTIONS

To prevent injury to the user, other people, or property damage, the following instructions must be followed. Incorrect operation due to ignoring of instructions may cause harm or damage.

Install the unit only when it complies with local regulations, by-laws and standards. Check the main voltage and frequency. This unit is only suitable for earthed sockets, connection voltage 220 – 240 V ~ / 50Hz.

The following safety precautions should always be taken into account:

- Be sure to read the following WARNING before installing the unit.
- Be sure to observe the cautions specified here as they include important items related to safety.
- After reading these instructions, be sure to keep it in a handy place for future reference.

Warning



Do not install the unit yourself.

Incorrect installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or a specialized installer.

Install the unit securely in a place.

When insufficiently installed, the unit could fall causing injury. The bearing surface should be flat to bear the weight of the unit and suitable for installing the unit without increasing noise or vibration. When installing the unit in a small room, please take measures (like sufficient ventilation) to prevent the asphyxia caused by the leakage of refrigerant.

Use the specified electrical wires and attach the wires firmly to the terminal board (connection in such a way that the stress of the wires is not applied to the sections).

Incorrect connection and fixing could cause a fire.

Be sure to use the provided or specified parts for the installation work.

The use of defective parts could cause an injury due to possible fire, electric shocks, the unit falling etc.

Perform the installation securely and please refer to the installation instructions.

Incorrect installation could cause an injury due to possible fire, electric shocks, the unit falling, leakage of water etc.

Perform electrical work according to the installation manual and be sure to use a dedicated section, fused with 16A.

If the capacity of the power circuit is insufficient or there is an incomplete electrical circuit, it could result in a fire or an electric shock.

The unit must always have an earthed connection.

If the power supply is not earthed, you may not connect the unit.

Never use an extension cable to connect the unit to the electric power supply.

If there is no suitable, earthed wall socket available, have one installed by a recognized electrician.

Do not move/repair the unit yourself.

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard. Improper movement or repair on the unit could lead to water leakage, electrical shock, injury or fire.

The unit is no intended for use by children.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Do not tear off the labels on the unit.

The labels are for the purpose of warning or reminding, keeping them can ensure your safe operations.

Caution



CAUTION

Do not install the unit in a place where there is a chance of flammable gas leaks.

If there is a gas leak and gas accumulates in the area surrounding the unit, it could cause an explosion.

Perform the drainage/piping work according to the installation instruction.

If there is a defect in the drainage/piping work, water could leak from the unit and household goods could get wet and be damaged.

Do not clean the unit when the power is 'ON'.

Always shut 'OFF' the power when cleaning or servicing the unit. If not, it could cause an injury due to the high speed running fan or an electrical shock.

Do not continue to run the unit when there is something wrong or there is a strange smell.

The power supply needs to be shut 'OFF' to stop the unit; otherwise this may cause an electrical shock or fire.

Do not put your fingers or others into the fan, or evaporator.

The inside parts of the heat pump may run at high speed or high temperature, they could cause serious injury. Do not remove the grills on the fan outlet and top cover.

The hot water probable need to mix with cold water for terminal usage, too hot water (over 50°C) in the heating unit may cause injury.

The installation height of power supply should be over 1.8m, if any water may spatter, the unit can be safe from water.


ITEMS INSIDE PRODUCT BOX

Before starting the installation, please make sure that all parts are found inside the box.

| The Unit Box | | |
|---------------------------------|--|----------|
| Item | Image | Quantity |
| Domestic hot water heat pump |  | 1 |
| Operation & Installation Manual | <p>Operation & Installation Manual .</p> <p>--For Sanitary Hot Water Heat Pump--</p>  <p>Subsidiary for model Smart Air 100L, 100Lx</p> | 1 |


OVERVIEW OF THE UNIT

Parts and descriptions



Dimensions

Model: 100L



Top cover

Bottom plate

| REGINA SMART 100L | | | |
|-------------------|------|---|--------|
| A | Φ520 | F | 1367.5 |
| B | Φ120 | G | 370 |
| C | 280 | H | 739 |
| D | 100 | J | 35 |
| E | 130 | \ | \ |

Remark:


- 1) The extra heat source is optional.
- 2) The Magnesium stick is an anti-corrosion element. It is assembled in the water tank to avoid the creation of fur around the inside tank and to protect the tank, and other components. It can help to extend the life-span of the tank. **Check the magnesium stick every half year and change it if it has been used out !**

How to replace the magnesium anode



- Turn the power of the unit 'OFF' and pull out the plug.
- Drain all the water out of the tank.
- Remove the old magnesium anode from the tank.
- Replace the new magnesium anode.
- Recharge the water.

Schematic overview of the water and refrigeration circuit



Choose the suitable unit

Please refer to the table below to choose the suitable unit.

| Family members | Tank capacity |
|----------------|-------------------|
| 1 ~ 2 people | REGINA SMART 100L |
| | |
| | |

Note: The table is just for reference.

INSTALLATION

WARNING

- Asked your supplier to install the unit. Incomplete installation performed by yourself may result in a water leakage, electric shock, or fire.
- Indoor installation is highly recommended. It is not allow to install the unit at outdoor or rain achieving place.
- The installation place without direct sunlight and other heat supplies is recommended. If no way to avoid these, please install a covering.
- The unit must be securely fixed to avoid noise and shaking.
- Make sure that there's no remora around the unit.
- In the place where there is strong wind, fix the unit in the location protected from the wind.

Transportation


As a rule, the unit is to be stored and/or transported in its shipping container in upright position and without water charge. For a transport over short distance (provided that it is done with care), an inclination angle up to 30 degrees is permitted, both during transport and storage. Ambient temperatures of -20 to $+70$ degrees Celsius are permitted.

- **Transport using a forklift**

When transported by a forklift, the unit must remain mounted on the pallet. The lifting rate should be kept to a minimum. Due to its top-heaviness, the unit must be secured against tipping over. To prevent any damage, the unit must be placed on a level surface.

- **Manual transport**


For the manual transport, a wooden/plastic pallet can be used. Using ropes or carrying straps, a second or third handling configuration is possible. With this type of handling, it is advised that the maximum permissible inclination angle of 45 degree is not exceeded. If transport in an inclined position cannot be avoided, the unit should be taken into operation one hour after it has been moved into final position.



ATTENTION: DUE TO THE HIGH CENTER OF GRAVITY, LOW OVERTURNING MOMENT, THE UNIT MUST BE SECURED AGAINST TIPPING OVER.

Required service space


Below you will find the minimum space required to be able to complete service and maintenance tasks on the units.



Note:

- If air inlet and/or outlet pipes are connected, portion airflow and capacity in heat pump unit will lose.
- If the unit connects with air ducts it should be DN 180mm for pipes or 180mm internal diameter flexible hose. Total length of the ducts should not be longer than 8m or the maximum static pressure should not exceed than 60Pa. Be in mind of bending site of the duct no more than 4m.

Installation overview



Note: Solar heat exchange coil is optional.



ATTENTION:

- The one-way safety valve must be installed. If not, it could cause damage to the unit, or even hurt people. The set point of this safety valve is 0.7 MPa. For the installation place please refer to the pipeline connection sketch.
- The discharge pipe connected to the one-way safety valve is to be installed in a continuously downward direction and in a frost-free environment.
- The water may drip from the discharge pipe of the one-way safety valve and that this pipe must be left open to the atmosphere.
- The one-way safety valve is to be operated regularly to remove lime deposits and to verify that it is not blocked. Please beware of burn, because of the high temperature of water.

- The tank water can be drained through the drainage hole on the bottom of the tank.
- After all the pipes installed turn on the cold water inlet and hot water outlet to fill the tank. When there is water normally following out from water outlet, the tank is full. Turn off all valves and check all pipes. If any leakage, please repair.
- If the inlet water pressure is less than 0.15MPa, a pressure pump should be installed at the water inlet. For ensure the long safety using age of tank at the condition of water supply hydraulic higher than 0.65MPa, a reducing valve should be mounted at the water inlet pipe.
- Filters are needed in the air inlet. If the unit is connected with ducts, filter in there must be put forward to the air inlet of duct.
- To fluently drain condensate water from evaporator, please install the unit at the horizontal floor. Otherwise, please make sure the drain vent is at the lowest place. Recommending the inclination angle of unit to be ground should no more than 2 degree.

Installation positions

(1) Waste heat can be useful heat

Units can be installed near the kitchen, in the boiler-room or the garage, basically in every room which has a large number of waste-heat so that the unit has the higher energy efficiency even with very low outside temperatures during the winter.

(2) Hot water and dehumidification

Units can be placed in the laundry room or clothing room. When it produces hot water it lowers the temperature and dehumidifies the room as well. The advantages can be experienced particularly in the humid season.

(3) Solar panel or external heat pump could be the second heat source

Units can work with solar panel, external heat pump, boiler or other different energy source.

NOTE:

- Choose the right path to move the unit.
- This unit complies with the relevant technical standards of electrical equipment.

Water loop connection

Please pay attention to the below points when connecting the water loop pipe:

1. Try to reduce the water loop resistance
2. Make sure there is nothing in the pipe and the water loop is smooth, check the pipe carefully to see if there is any leak, and then pack the pipe with the insulation.
3. Install the one way valve and safety valve in the water circulation system.
4. The nominal pipe wide of the field- installed sanitary installations must be selected on the basis of the available water pressure and the expected pressure drop within the piping system.
5. The water pipes may be of the flexible type. To prevent corrosion damage, make sure that the materials used in the piping system are compatible.
6. When installing the pipe-work on the customers' site, any contamination of the piping system must be avoided.

Water affusion and water emptying

Water Affusion:

If the unit is used for the first time or used again after emptying the tank, please make sure that the tank is full of water before turning on the power.

- Open the cold water inlet and hot water outlet.
- Start the water affusion. When there is water normally flowing out from the hot water outlet, the tank is full.
- Turn off the hot water outlet valve and water affusion is finished.



ATTENTION: Operation without water in water tank may result in damage of auxiliary e-heater!

Water emptying:

If the unit needs cleaning, moving etc, the tank should be emptied.

- Close the cold water inlet
- Open the hot water outlet and open the manual valve of drainpipe
- Start the water emptying.
- After emptying, close the manual valve.

Wire connection

- The specification of the power supply wire is 3*1.5 mm².
- Fuse specification is 16A 250V
- The unit must be installed a Creepage Breaker near the power supply and must be effectively earthed. The specification of the creepage breaker is 30mA, less than 0.1sec.

THE APPLIANCE SHALL BE INSTALLED IN ACCORDANCE WITH NATIONAL WIRING REGULATIONS.


Trial running

Checks before trial running

- Check both the water in the tank as well as the water pipe connection.
- Check the power system, make sure that the power supply is normal and the wire connection is ok.
- Check the inlet water pressure, and make sure that the pressure is sufficient (above 0.15Mpa).
- Check if any water flows out from the hot water outlet, and make sure that the tank is full of water before turning on the power.
- Check the unit; make sure everything is ok before turning 'ON' the power of the unit, check the light on the wire controller when the unit runs.
- Use the wire controller to start the unit.
- Listen to the unit carefully when turning 'ON' the power of the unit. Turn the power 'OFF' when you hear an abnormal sound.
- Measure the water temperature, to check the undulation of the water temperature.
- Once the parameters have been set, the user cannot change the parameters optionally. Please use a qualified service person to do this.

OPERATION THE UNIT

User interface and operation



Operations

1. Power 'ON'

When turning 'ON' the power, whole icons are displayed on the controller screen for 3 seconds. After checking if everything is ok, the unit enters into the standby mode.



2. button

Press this button and keep for 3 seconds when the unit is standby, the unit can be turned 'ON'. Press this button and keep for 3 seconds when the unit is running, the unit can be turned 'OFF'. Short press this button to exit the parameter setting or checking.



3. ▲ And ▼ buttons

- These are the multi-purpose buttons. They are used for the temp setting, parameter setting, parameter checking, clock adjustment and adjustment of the timer.
- During running status, press ▲ or ▼ button to adjust the setting temperature directly.
- Press these buttons when the unit is on clock setting status, the hour(s) and the minute(s) of the clock time can be adjusted.
- Press these buttons when the unit is on timer setting status, the hour(s) and the minute(s) of the timer 'ON'/'OFF' can be adjusted.

4. ⌚ button

Clock setting:

- Long press ⌚ 3s to unlock the screen;
- After screen is light, short press ⌚ to entry the clock setting interface, hour icon "88:" flash, press the ▲ and ▼ buttons to set the exact hour(s);
- After hour setting, short press ⌚ button to switch to minute setting, minute":88" flash, press the ▲ and ▼ buttons to set the exact minute(s);
- Press ⌚ button again to confirm and exit.

Timer setting:

Press and hold ⌚ the time button 3S to enter the timed on/off setting state. When entering the time setting, press the time button to set the clock and minute of the timed on/off (when the clock or minute flashes, combine ▲ and ▼. The clock and minutes can be adjusted). The timed on/off can be set independently. When the timed "ON" flashes, it means to cancel the timed start function. At this time, press the M button "ON" does not flash to indicate that the timed start function is on, then press the M button, "ON" flashes to cancel. Timed start function; continue to press the time button. When "OFF" appears, you can set the timed shutdown. When "OFF" flashes, it means to cancel the timed shutdown function. At this time, press the M button, "OFF" does not flash to indicate that the timed shutdown function is on, then Click the M button, and "OFF" flashes to cancel the timed shutdown function. In the case of lock screen, tap any button to light up the screen. After lighting the screen, press and hold the timer button for 3 seconds to unlock. If no operation for 30 seconds, the monitor automatically exits to the main interface and locks the screen.

NOTE:

- 1) The timer 'ON' and timer 'OFF' functions can be set at the same time.
- 2) The timer settings are repeating.
- 3) The timer settings are still valid after a sudden power cut.

5. **M** button

- When the screen is unlocked,

- 1) Short press **M**, the mode can be adjusted operating mode
 - AUTO Mode (heat pump +E-heater)
 - GREEN Mode (only heat pump will work at normal working situation)
 - Boost Mode (heat pump +E-heater work at the same time)
 - E-heater Mode (only E-heater will work)
 - Ventilation mode (only fans work)
- 2) Check the system parameters
 - Press this button and hold for 3 seconds, enter the system parameter checking interface.
 - Press the **▲** and **▼** buttons to check the system parameters.
- 3) Adjust the system parameters
 - Press **M** for 3 seconds, enter the parameter checking interface.
 - Press **▲** or **▼** button to select the parameter (parameter A-F can't be adjusted), and then press **M** to confirm it.
 - Press the **▲** and **▼** buttons to adjust the selecting parameter, and then press **M** to confirm the setting.

If no operation for 30 seconds, the controller will exit and save the setting automatically.

NOTE: The parameters have been set; the user cannot change the parameters optionally. Please ask a qualified service person to do this when required.

6. Error codes

During standby or running status, if there is a malfunction, the unit will stop automatically and show the error code on the left screen of the controller.



LCD icons

1. **Fan ventilation** 

The icon indicates that the fan ventilation function is enabled.

2. **Electrical heating** 

The icon indicates that the electrical heating function is enabled. The electrical heater will work according to the control program.

3. **Defrosting** 

This icon shows the heat pump is under defrosting

4. **Heating** 

This icon shows the heat pump is working

5. **Heating + Electrical** 

This icons show that the heat pump is working, and the electrical is working as well

6. **Left temperature display** 

The display shows the setting water temperature.

When checking or adjusting the parameters, this section will display the relating parameter number.

7. **Right temperature display** 

The display shows the current downside temperature of the water tank.

When checking or adjusting the parameters, this section will display the related parameter value.

In case any malfunction occurs, this section will display the related error code.

8. **Time display** 

The display shows the clock time or timer time.

9. **Timer 'ON'** 

The icon indicates that the timer 'ON' function is enabled.

10. **Timer 'OFF'** 

The icon indicates that the timer 'OFF' function is enabled.

11. **Error** 

The icon indicates there is malfunction.

PARAMETER CHECKING AND ADJUSTMENT

Parameter list

Some parameters can be checked and adjusted by the controller. Below is the parameter list.

| Parameter No. | Description | Range | Default | Remarks |
|---------------|--|------------------------|---|------------------|
| A | Lower tank water temp. | -20 ~ 99°C | Actual testing value. Error code P01 will be shown in case of a malfunction | |
| B | Upper tank water temp. | -20 ~ 99°C | Actual testing value. Error code P02 will be shown in case of a malfunction | |
| C | Evaporator coil temp. | -20 ~ 99°C | Actual testing value. Error code P03 will be shown in case of a malfunction | |
| D | Return gas temp. | -20 ~ 99°C | Actual testing value. Error code P04 will be shown in case of a malfunction | |
| E | Ambient temp. | -20 ~ 99°C | Actual testing value. Error code P05 will be shown in case of a malfunction | |
| F | Electronic expansion valve step | 10 ~ 47 step | N*10 step | |
| 01 | Lower tank water temp and the setting temp. difference | 2 ~ 15°C | 5°C | Adjustable |
| 02 | Holiday mode valid days | 3 ~ 90 days | 7 days | Reserved |
| 03 | E-heater delay time | 0 ~ 90min | 6 | Reserved |
| 04 | Week disinfection temperature | 50 ~ 70°C | 70°C | Adjustable |
| 05 | High temp disinfection time | 0 ~ 90 min | 30 min | Adjustable |
| 06 | Defrosting period | 30~90 min | 45 min | Adjustable |
| 07 | Defrosting entry coil temp. | -30 ~ 0°C | -7°C | Adjustable |
| 08 | Defrosting exit coil temp. | 2 ~ 30°C | 20°C | Adjustable |
| 09 | Max defrosting cycle period | 1 ~ 12 min | 8 min | Adjustable |
| 10 | Electronic expansion valve adjustment | 0 (auto) 1 (manual) | 0 | Adjustable |
| 11 | Target over-heat degree | -9 ~ 9°C | 5°C | Adjustable |
| 12 | Steps of manually adjusting the electronic expansion valve | 10 ~ 47 step | 35 step | Adjustable(N*10) |
| 13 | Disinfection start up time adjusting | 0~23 | 23 | Adjustable(hour) |
| 14 | E-heat start temp. difference | 2 ~ 20°C | 7°C | Adjustable |
| 15 | Compressor accumulative running time | 10 ~ 80 min | 30 min | Adjustable |
| 16 | Lower tank water temp. raise | 0 ~ 20°C | 2°C | Adjustable |

Malfunctioning of the unit and error codes

When an error occurs or the protection mode is set automatically, the circuit board and the wired controller will both display the error message.

| Protection/ Malfunction | Error code | LED indicator | Possible reasons | Corrective actions |
|---------------------------------------|---------------|-----------------------------------|---|---|
| Standby | | Dark | | |
| Normal running | | Bright | | |
| Lower tank water temp. sensor failure | P01 | ☆● (1flash 1 dark) | 1) The sensor open circuit 2) The sensor short circuit | 1) Check the sensor connection 2) Replace the sensor |
| Upper tank water temp. sensor failure | P02 | ☆☆● (2 flashes 1 dark) | 1) The sensor open circuit 2) The sensor short circuit | 1) Check the sensor connection 2) Replace the sensor |
| Evaporator coil temp. sensor failure | P03 | ☆☆☆● (3 flashes 1 dark) | 1) The sensor open circuit 2) The sensor short circuit | 1) Check the sensor connection 2) Replace the sensor |
| Return gas temp sensor failure | P04 | ☆☆☆☆● (4 flashes 1 dark) | 1) The sensor open circuit 2) The sensor short circuit | 1) Check the sensor connection 2) Replace the sensor |
| Ambient temp. sensor failure | P05 | ☆☆☆☆☆ ● (5 flashes 1 dark) | 1) The sensor open circuit 2) The sensor short circuit | 1) Check the sensor connection 2) Replace the sensor |
| High pressure protection (HP Switch) | E01 | ☆☆☆☆☆ ☆● (6 flashes 1 dark) | 1) Too high air inlet temp 2) Less water in the tank 3) The electronic expansion valve assembly blocked 4) Too much refrigerant 5) The switch damaged 6) The uncompressed gas is in refrigerant system | 1) Check if the air inlet temp is over the working limited 2) Check if the tank is full of water. If not, charge water 3) Replace the electronic expansion valve assembly 4) Discharge some refrigerant 5) Replace a new switch 6) Discharge and then recharge the refrigerant |

| | | | | |
|--|----------------------|--------------------------------------|---|---|
| Low pressure protection (LP Switch) | E02 | ☆☆☆☆☆ ☆☆● (7 flashes 1 dark) | 1) Too low air inlet temp 2) The electronic expansion valve assembly blocked 3) Too less refrigerant 4) The switch damaged 5) The fan assembly can not work | 1) Check if the air inlet temp is over the working limited 2) Replace the electronic expansion valve assembly 3) Charge some refrigerant 4) Replace a new switch 5) Check if the fan working when the compressor working. If not, some problems with the fan assembly |
| Over heat protection (HTP Switch) | E03 | ☆☆☆☆☆ ☆☆☆● (8 flashes 1 dark) | 1) Too high tank water temp 2) The switch damaged | 1) If the tank water temp is over 85C, the switch will open and the unit will stop for protection. After the water comes to normal temp, 2) Replace a new switch |
| Compressor protection (out of the ambient limit or water temp limit) | PA | ☆☆☆☆☆ ☆☆☆☆● (9 flashes 1 dark) | 1) Tank water temp too high 2) The switch damaged | 1) If the tank water temp is over 85C, the switch will open and the unit will stop for protection. After the water comes to normal temp, 2) Replace a new switch |
| Defrost | Defrosting indicator | ☆☆☆☆☆ ☆☆☆.....(all long flashes) | | |
| Communication failure | E08 | Bright | | |

MAINTENANCE

Maintenance activities

In order to ensure an optimum operation of the unit, a number of checks and inspections on the unit and the field wiring have to be carried out at regular intervals, preferably yearly.

- Check the water supply and air vent frequently, to avoid lack of water or air in the water loop.
- Clean the water filter to keep a good water quality. Lack of water and dirty water can damage the unit.
- Keep the unit in a place where it is dry and clean, and which has good ventilation. Clean the heat exchanger every one to two months.
- Check each part of the unit and the pressure of the system. Replace the defect part if there is any, and recharge the refrigerant if it is required.
- Check the power supply and the electrical system, make sure the electrical components are good, and the wiring is well. If there is a damaged part or a strange smell, please replace it in time.
- If the heat pump is not used for a long time, please drain out all the water from the unit and seal the unit to keep it good. Please drain the water from the lowest point of the boiler to avoid freezing in winter. Water recharge and full inspection on the heat pump is required before it is restarted.
- Do not turn the power 'OFF' when you use the unit continuously, or the water in the pipe will freeze and split the pipe.
- Keep the unit clean by means of soft damp cloth, no maintenance is required by the operator.
- It is recommended to clean the tank and e-heater regularly to keep an efficient performance.
- It is recommended to set a lower temperature to decrease the heat release, prevent scale and save energy if the outlet water is sufficient.
- Clean the air filter regularly to keep an efficient performance.

TROUBLESHOOTING

This section provides useful information for diagnosing and correcting certain troubles which may occur. Before starting the troubleshooting procedure, carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring.

Before contacting your local dealer, read this chapter carefully, it will save you time and money.



WHEN CARRYING OUT AN INSPECTION ON THE SWITCH BOX OF THE UNIT, ALWAYS MAKE SURE THAT THE MAIN SWITCH OF THE UNIT IS SWITCHED 'OFF'.

The guidelines below might help to solve your problem. If you cannot solve the problem, consult your installer/local dealer.

- No image on the controller (blank display). Check if the main power is still connected.
- One of the error codes appears, consult your local dealer.
- The scheduled timer does work but the programmed actions are executed at the wrong time (e.g. 1 hour too late or too early). Check if the clock and the day of the week are set correctly, adjust if necessary.

ENVIRONMENTAL INFORMATION

This equipment contains fluorinated greenhouse gases covered by the Kyoto Protocol. It should only be serviced or dismantled by professional trained personnel.

This equipment contains R134a refrigerant in the amount as stated in the specification. Do not vent R134a into the atmosphere: R134a, is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 1975.

DISPOSAL REQUIREMENTS

Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.




Your product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Units must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring that this product is disposed off correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

WIRING DIAGRAM

Please refer to the wiring diagram on the electric box.




TECHNICAL SPECIFICATION

| Model | | REGINA SMART 100L |
|--|---------|-------------------|
| Capacity | kW | 0.85* (+1.5**) |
| Energy Class (ERP) | | A+*** |
| COP (ERP) | | 3.2*** |
| Duct air flow (nom.) | m³/h | 300 |
| Rated power input | W | 246 (+1500**) |
| Current (nom.) | A | 1.16* (+6.5**) |
| Current (Rated.) | A | 1.81(+6.5**) |
| Power supply | V/Ph/Hz | 220-240~/1/50 |
| Max outlet water temperature (without using E-heater) | °C | 60 |
| Refrigerant | .../g | R134a/600 |
| Rated water yield | L/H | 19 |
| Max. Water operating pressure | Mpa | 1.0 |
| Rated water pressure | Mpa | 0.6 |
| Set point relief valve | Mpa | 0.7 |
| Sound pressure level | dB (A) | 48.5 |
| Net weight | kg | 50 |
| Net size (WxHxD) | mm | φ520x1368 |
| Package Size (WxHxD) | mm | 580x580x1515 |
| * Capacity and power input based on the following conditions: Ambient temperature 20°C /15°C, water temperature from 15°C to 55°C. | | |
| **Related to the supplementary heater | | |
| *** Water heating energy efficiency based on standard ERP, M cycle: Ambient temperature 7°C /6°C, water temperature from 10°C to 55°C. | | |

TEMPERATURE SENSOR R-T CONVERSION TABLE

R25= 5.0KΩ±1.0% B25-50 = 3470K±1.0%

| °C | Rmin /KΩ | KΩ | Rmax/ KΩ | °C | Rmin /KΩ | KΩ | Rmax/ KΩ | °C | Rmin /KΩ | KΩ | Rmax/ KΩ |
|-----|----------|--------|----------|----|----------|-------|----------|-----|----------|-------|----------|
| -20 | 36.195 | 37.303 | 38.441 | 21 | 5.779 | 5.847 | 5.914 | 62 | 1.343 | 1.374 | 1.406 |
| -19 | 34.402 | 35.437 | 36.499 | 22 | 5.558 | 5.62 | 5.683 | 63 | 1.301 | 1.331 | 1.362 |
| -18 | 32.709 | 33.676 | 34.668 | 23 | 5.346 | 5.404 | 5.463 | 64 | 1.26 | 1.29 | 1.321 |
| -17 | 31.109 | 32.012 | 32.939 | 24 | 5.144 | 5.198 | 5.252 | 65 | 1.221 | 1.25 | 1.28 |
| -16 | 29.597 | 30.441 | 31.306 | 25 | 4.95 | 5 | 5.05 | 66 | 1.183 | 1.212 | 1.242 |
| -15 | 28.168 | 28.957 | 29.765 | 26 | 4.761 | 4.811 | 4.861 | 67 | 1.147 | 1.175 | 1.204 |
| -14 | 26.816 | 27.554 | 28.308 | 27 | 4.58 | 4.63 | 4.68 | 68 | 1.111 | 1.139 | 1.168 |
| -13 | 25.538 | 26.227 | 26.932 | 28 | 4.408 | 4.457 | 4.507 | 69 | 1.077 | 1.105 | 1.133 |
| -12 | 24.328 | 24.972 | 25.631 | 29 | 4.242 | 4.292 | 4.341 | 70 | 1.045 | 1.072 | 1.099 |
| -11 | 23.183 | 23.785 | 24.4 | 30 | 4.084 | 4.133 | 4.182 | 71 | 1.013 | 1.04 | 1.067 |
| -10 | 22.098 | 22.661 | 23.236 | 31 | 3.933 | 3.981 | 4.03 | 72 | 0.983 | 1.009 | 1.035 |
| -9 | 21.071 | 21.598 | 22.135 | 32 | 3.788 | 3.836 | 3.885 | 73 | 0.953 | 0.979 | 1.005 |
| -8 | 20.098 | 20.59 | 21.093 | 33 | 3.649 | 3.697 | 3.745 | 74 | 0.925 | 0.95 | 0.975 |
| -7 | 19.176 | 19.636 | 20.106 | 34 | 3.516 | 3.563 | 3.611 | 75 | 0.897 | 0.922 | 0.947 |
| -6 | 18.301 | 18.732 | 19.171 | 35 | 3.388 | 3.435 | 3.483 | 76 | 0.871 | 0.895 | 0.919 |
| -5 | 17.472 | 17.875 | 18.285 | 36 | 3.266 | 3.313 | 3.36 | 77 | 0.845 | 0.869 | 0.893 |
| -4 | 16.686 | 17.063 | 17.446 | 37 | 3.149 | 3.195 | 3.241 | 78 | 0.82 | 0.843 | 0.867 |
| -3 | 15.94 | 16.292 | 16.65 | 38 | 3.037 | 3.082 | 3.128 | 79 | 0.796 | 0.819 | 0.842 |
| -2 | 15.231 | 15.561 | 15.896 | 39 | 2.929 | 2.974 | 3.019 | 80 | 0.773 | 0.795 | 0.818 |
| -1 | 14.559 | 14.867 | 15.18 | 40 | 2.826 | 2.87 | 2.915 | 81 | 0.751 | 0.773 | 0.795 |
| 0 | 13.92 | 14.208 | 14.501 | 41 | 2.726 | 2.77 | 2.815 | 82 | 0.729 | 0.751 | 0.773 |
| 1 | 13.313 | 13.582 | 13.856 | 42 | 2.631 | 2.675 | 2.718 | 83 | 0.708 | 0.729 | 0.751 |
| 2 | 12.736 | 12.988 | 13.244 | 43 | 2.54 | 2.583 | 2.626 | 84 | 0.688 | 0.709 | 0.73 |
| 3 | 12.188 | 12.423 | 12.662 | 44 | 2.452 | 2.494 | 2.537 | 85 | 0.668 | 0.689 | 0.709 |
| 4 | 11.666 | 11.887 | 12.11 | 45 | 2.368 | 2.409 | 2.451 | 86 | 0.649 | 0.669 | 0.69 |
| 5 | 11.17 | 11.376 | 11.585 | 46 | 2.287 | 2.328 | 2.369 | 87 | 0.631 | 0.651 | 0.671 |
| 6 | 10.698 | 10.891 | 11.086 | 47 | 2.209 | 2.25 | 2.29 | 88 | 0.613 | 0.632 | 0.652 |
| 7 | 10.249 | 10.429 | 10.611 | 48 | 2.135 | 2.174 | 2.214 | 89 | 0.596 | 0.615 | 0.634 |
| 8 | 9.822 | 9.99 | 10.16 | 49 | 2.063 | 2.102 | 2.141 | 90 | 0.579 | 0.598 | 0.617 |
| 9 | 9.414 | 9.572 | 9.73 | 50 | 1.994 | 2.032 | 2.071 | 91 | 0.563 | 0.581 | 0.6 |
| 10 | 9.027 | 9.173 | 9.321 | 51 | 1.927 | 1.965 | 2.003 | 92 | 0.548 | 0.566 | 0.584 |
| 11 | 8.657 | 8.794 | 8.932 | 52 | 1.863 | 1.901 | 1.938 | 93 | 0.533 | 0.55 | 0.568 |
| 12 | 8.305 | 8.432 | 8.561 | 53 | 1.802 | 1.839 | 1.876 | 94 | 0.518 | 0.535 | 0.553 |
| 13 | 7.969 | 8.088 | 8.208 | 54 | 1.743 | 1.779 | 1.815 | 95 | 0.504 | 0.521 | 0.538 |
| 14 | 7.648 | 7.76 | 7.872 | 55 | 1.686 | 1.721 | 1.757 | 96 | 0.49 | 0.507 | 0.524 |
| 15 | 7.343 | 7.446 | 7.551 | 56 | 1.631 | 1.666 | 1.701 | 97 | 0.477 | 0.493 | 0.51 |
| 16 | 7.051 | 7.148 | 7.245 | 57 | 1.579 | 1.613 | 1.647 | 98 | 0.464 | 0.48 | 0.496 |
| 17 | 6.773 | 6.863 | 6.953 | 58 | 1.528 | 1.561 | 1.595 | 99 | 0.452 | 0.467 | 0.483 |
| 18 | 6.507 | 6.5911 | 6.675 | 59 | 1.479 | 1.512 | 1.545 | 100 | 0.439 | 0.455 | 0.47 |
| 19 | 6.253 | 6.331 | 6.41 | 60 | 1.432 | 1.464 | 1.497 | | | | |
| 20 | 6.011 | 6.083 | 6.156 | 61 | 1.386 | 1.418 | 1.451 | | | | |



ZANTIA[®]

Inspired by *Comfort!*

WWW.ZANTIA.COM